


DTC P0113[ZJ, ZY, Z6]

mazdamanuals.com

Without Throttle Valve Actuator

DTC P0113	IAT sensor circuit high input
DETECTION CONDITION	<ul style="list-style-type: none">• The PCM monitors the input voltage from the IAT sensor. If the input voltage is more than 4.8 V, the PCM determines that the IAT sensor circuit has a malfunction. <p>Diagnostic support note</p> <ul style="list-style-type: none">• This is a continuous monitor (CCM).• The MIL illuminates if the PCM detects the above malfunction condition in the first drive cycle.• PENDING CODE is available if the PCM detects the above malfunction condition.• FREEZE FRAME DATA is available.• The DTC is stored in the PCM memory.
POSSIBLE CAUSE	<ul style="list-style-type: none">• IAT sensor malfunction• Connector or terminal malfunction• Open circuit in wiring harness between MAF/IAT sensor terminal D and PCM terminal 2AQ• Short to power supply in wiring harness between MAF/IAT sensor terminal D and PCM terminal 2AQ• Open circuit in wiring harness between MAF/IAT sensor terminal E and PCM terminal 2AY• PCM malfunction



Diagnostic procedure


STEP	INSPECTION	ACTION
1	VERIFY FREEZE FRAME DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has FREEZE FRAME DATA been recorded? 	Yes Go to the next step.
		No Record the FREEZE FRAME DATA on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No Go to the next step.
3	INSPECT MAF/IAT SENSOR CONNECTOR FOR POOR CONNECTION <ul style="list-style-type: none"> Turn the ignition switch off. 	Yes Repair or replace the terminal, then go to Step 8.

	<ul style="list-style-type: none"> • Disconnect the MAF/IAT sensor connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	No	Go to the next step.
4	INSPECT IAT SENSOR SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Turn the ignition switch to the ON position (Engine off). • Measure the voltage between MAF/IAT sensor terminal D (wiring harness-side) and body ground. • Is the voltage B+? 	Yes	Repair or replace the wiring harness for a possible short to power supply, then go to Step 8.
		No	Go to the next step.
5	INSPECT IAT SENSOR <ul style="list-style-type: none"> • Inspect the IAT sensor. (See INTAKE AIR TEMPERATURE (IAT) SENSOR INSPECTION[ZJ, ZY, Z6].) • Is there any malfunction? 	Yes	Replace the MAF/IAT sensor, then go to Step 8. (See MASS AIR FLOW (MAF)/INTAKE AIR TEMPERATURE (IAT) SENSOR REMOVAL/INSTALLATION[ZJ, ZY, Z6].)
		No	Go to the next step.
6	INSPECT PCM CONNECTOR FOR POOR CONNECTION <ul style="list-style-type: none"> • Turn the ignition switch off. • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the terminal, then go to Step 8.
		No	Go to the next step.
7	INSPECT IAT SENSOR CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Turn the ignition switch off. • Inspect for continuity between the following terminals: <ul style="list-style-type: none"> — MAF/IAT sensor terminal D (wiring harness-side) and PCM terminal 2AQ (wiring harness-side) — MAF/IAT sensor terminal E (wiring harness-side) and PCM terminal 2AY (wiring harness-side) • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to the next step.
8	VERIFY TROUBLESHOOTING OF DTC P0113 COMPLETED <ul style="list-style-type: none"> • Make sure to reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. • Start the engine. 	Yes	Replace the PCM, then go to the next step. (See PCM REMOVAL/INSTALLATION[ZJ, ZY, Z6].)
		No	Go to the next step.

	• Is the same DTC present?		
9	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE[ZJ, ZY, Z6].) <ul style="list-style-type: none"> Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE[ZJ, ZY, Z6].)
		No	DTC troubleshooting completed.

With Throttle Valve Actuator

DTC P0113	IAT sensor circuit high input
DETECTION CONDITION	<ul style="list-style-type: none"> The PCM monitors the input voltage from the IAT sensor. If the input voltage is more than 4.8 V, the PCM determines that the IAT sensor circuit has a malfunction. Diagnostic support note <ul style="list-style-type: none"> This is a continuous monitor (CCM). The MIL illuminates if the PCM detects the above malfunction condition in the first drive cycle. PENDING CODE is available if the PCM detects the above malfunction condition. FREEZE FRAME DATA is available. The DTC is stored in the PCM memory.
POSSIBLE CAUSE	<ul style="list-style-type: none"> IAT sensor malfunction Connector or terminal malfunction Open circuit in wiring harness between MAF/IAT sensor terminal D and PCM terminal 2R Short to power supply in wiring harness between MAF/IAT sensor terminal D and PCM terminal 2R Open circuit in wiring harness between MAF/IAT sensor terminal E and PCM terminal 2Q PCM malfunction



Diagnostic procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has FREEZE FRAME DATA been recorded? 	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. <ul style="list-style-type: none"> If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT MAF/IAT SENSOR CONNECTOR FOR POOR CONNECTION	Yes	Repair or replace the terminal, then go to Step 8.

	<ul style="list-style-type: none"> • Turn the ignition switch off. • Disconnect the MAF/IAT sensor connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	No	Go to the next step.
4	INSPECT IAT SENSOR SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Turn the ignition switch to the ON position (Engine off). • Measure the voltage between MAF/IAT sensor terminal D (wiring harness-side) and body ground. • Is the voltage B+? 	Yes	Repair or replace the wiring harness for a possible short to power supply, then go to Step 8.
		No	Go to the next step.
5	INSPECT IAT SENSOR <ul style="list-style-type: none"> • Inspect the IAT sensor. (See INTAKE AIR TEMPERATURE (IAT) SENSOR INSPECTION[ZJ, ZY, Z6].) • Is there any malfunction? 	Yes	Replace the MAF/IAT sensor, then go to Step 8. (See MASS AIR FLOW (MAF)/INTAKE AIR TEMPERATURE (IAT) SENSOR REMOVAL/INSTALLATION[ZJ, ZY, Z6].)
		No	Go to the next step.
6	INSPECT PCM CONNECTOR FOR POOR CONNECTION <ul style="list-style-type: none"> • Turn the ignition switch off. • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the terminal, then go to Step 8.
		No	Go to the next step.
7	INSPECT IAT SENSOR CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Turn the ignition switch off. • Inspect for continuity between the following terminals: <ul style="list-style-type: none"> — MAF/IAT sensor terminal D (wiring harness-side) and PCM terminal 2R (wiring harness-side) — MAF/IAT sensor terminal E (wiring harness-side) and PCM terminal 2Q (wiring harness-side) • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to the next step.
8	VERIFY TROUBLESHOOTING OF DTC P0113 COMPLETED <ul style="list-style-type: none"> • Make sure to reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. 	Yes	Replace the PCM, then go to the next step. (See PCM REMOVAL/INSTALLATION[ZJ, ZY, Z6].)
		No	Go to the next step.

	<ul style="list-style-type: none"> • Start the engine. • Is the same DTC present? 		
9	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE[ZJ, ZY, Z6].) <ul style="list-style-type: none"> • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE[ZJ, ZY, Z6].)
		No	DTC troubleshooting completed.