For Australia, New Zealand

Maintenance Interval		Number of months or kilometers, whichever comes first															
	Months	**6**	**12**	**18**	**24**	**30**	**36**	**42**	**48**	**54**	**60**	**66**	**72**	**78**	**84**	**90**	**96**
	×1000 km	**10**	**20**	**30**	**40**	**50**	**60**	**70**	**80**	**90**	**100**	**110**	**120**	**130**	**140**	**150**	**160**
GASOLINE ENGINE																	
Engine valve clearance		Audible inspect every 120,000 km, if noisy, adjust															
Air cleaner element *1				C			R			C			R			C	
Fuel filter		Replace every 150,000 km															
Spark plugs		Replace every 100,000 km															
Evaporative system (if installed)			I		I		I		I		I		I		I		I
DIESEL ENGINE																	
Engine valve clearance			I										I				
Engine timing belt *2		Replace every 120,000 km															
Air cleaner element *1			C		C		R		C		C		R		C		C
Fuel filter			R		R		R		R		R		R		R		R
Fuel injection system*3			I				I						I				
GASOLINE and DIESEL ENGINE																	
Engine oil *4*5		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
Engine oil filter *4		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
Drive belts *6		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Cooling system			I		I		I		I		I		I		I		I
Engine coolant	FL22 type *7	Replace at first 200,000 km or 10 years; after that, every 100,000 km or 5 years															
	Others	Replace at first 80,000 km or 4 years; after that, every 2 years															
Fuel lines and hoses			I		I		I		I		I		I		I		I
Battery electrolyte level and specific gravity			I		I		I		I		I		I		I		I
Brake lines, hoses and connections			I		I		I		I		I		I		I		I
Brake fluid *8		I	I	I	R	I	I	I	R	I	I	I	R	I	I	I	R
Parking brake		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Power brake unit (Brake booster) and hoses			I		I		I		I		I		I		I		I
Disc brakes		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Power steering fluid, lines, hoses and connections		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Steering operation and linkages			I		I		I		I		I		I		I		I
Manual transaxle oil											R						
Automatic transaxle fluid level			I		I		I		I		I		I		I		I
Front and rear suspension, ball joints and wheel bearing axial play			I		I		I		I		I		I		I		I
Drive shaft dust boots					I				I				I				I
Exhaust system and heat shields		Inspect every 80,000 km															
Bolts and nuts on chassis and body			T		T		T		T		T		T		T		T
All electrical system*9			I		I		I		I		I		I		I		I

Cabin air filter (if installed)				R				R				R				R
Tire rotation *10	Rotate every 10,000 km or 6 months															
Tires (including spare tire)(with inflation pressure adjustment)	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Road test	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
M-MDS check of Vehicle Management and Safety Systems		I		I		I		I		I		I		I		I