


## METER HOOD REMOVAL/INSTALLATION

id091700800900

1. Remove the upper column cover. (See COLUMN COVER REMOVAL/INSTALLATION.)
2. Move the meter hood in the order of arrows (1), (2), and (3) shown in the figure, and detach clips.



am6xuw00007505

3. Install in the reverse order of removal.